

Kurzbedienungsanleitung

1. Sicherheitshinweise

- Wechseln Sie aus Sicherheitsgründen sofort den werkseitig eingestellten Mastercode 1 2 3 4 5 6.
- Verwenden Sie für Ihren neuen Code keine persönlichen Daten z.B. Geburtstage oder andere Daten, auf die durch Kenntnis Ihrer Person rückgeschlossen werden könnte.
- Einfache Codes, die leicht zu erraten sind z.B. 1 2 3 4 5 6, dürfen nicht verwendet werden.
- Ihr Code muss geheim bleiben.
- Schreiben Sie den Code nicht auf.
- Speichern Sie den Code nicht auf Ihrem PC, einer DVD, einem USB-Stick oder Ihrem Handy.
- Ändern Sie Ihren Code regelmäßig, zum Beispiel alle drei Monate.
- Nach Eingabe eines neuen Codes sollte das Elektronischschloss bei offener Tür mehrmals mit dem neuen Code auf- und zugeschlossen werden.
- Kontrollieren Sie nach jedem Verschließen, dass das Wertbehältnis verschlossen ist.

Eine ausführliche Einbau-/Bedienungsanleitung finden Sie als Download auf unserer Website www.carl-wittkopp.com.

2. Öffnen

1. Geben Sie Ihren 6-stelligen (bzw. 7 stelligen, bei aktiver „stiller Alarm“ Funktion) Code ein. (Masterwerkscode 1 2 3 4 5 6 bzw. 1 2 3 4 5 6 0)
2. Drehen Sie innerhalb von 3 Sekunden den Tresorgriff in die „Offen“ - Position.

3. Verschließen

1. Verschließen Sie die Tür am Wertbehältnis und drehen Sie den Tresorgriff in die „Geschlossen“ - Position.

4. Anlegen eines Benutzercodes

Der Master kann einen Benutzercode anlegen, aber nicht umgekehrt.

1. Halten Sie die Taste „1“ gedrückt bis die roten LEDs dauerhaft leuchten.
2. Geben Sie Ihren 6-stelligen (bzw. 7 stelligen, bei aktiver „stiller Alarm“ Funktion) **Mastercode** ein.
3. Geben Sie die 1-stellige **Benutzer-Nr.** ein (zwischen 1 und 9), die angelegt werden soll.
4. Geben Sie den neuen 6 - stelligen (bzw. 7 stelligen, bei aktiver „stiller Alarm“ Funktion) **Benutzercode** ein.
5. Geben Sie erneut den neuen 6 -stelligen (bzw. 7 stelligen, bei aktiver „stiller Alarm“ Funktion) **Benutzercode** ein.

5. Ändern des Master- oder Benutzercodes

1. Halten Sie die Taste „0“ gedrückt bis die roten LEDs dauerhaft leuchten.
2. Geben Sie Ihren **alten** 6 bzw. 7-stelligen Code ein.
3. Geben Sie einen **neuen** 6 bzw. 7-stelligen Code ein.
4. Geben Sie erneut den **neuen** 6 bzw. 7-stelligen Code ein.

Quickstart

1. Notes on safety

- Due to security reasons change the factory code of 1 2 3 4 5 6 immediately.
- For your new code, do not use any personal data like birthdays or any other data, which could be known by knowledge of your person.
- Simple codes that can be guessed easily i.e. 1 2 3 4 5 6 must not be used.
- Your code has to be secret.
- Don't write down your code.
- Don't save your code on your PC, a DVD, a USB-stick or your mobile.
- Change your code frequently for example every three months.
- After entering the new code, the electronic lock should be opened and locked several times with the safe door opened.
- After each locking double-check if the safe is closed.

2. Opening

1. Enter your 7-digit code respectively 7 digits if "duress alarm" function is active.
(Factory master code 1 2 3 4 5 6 respectively 1 2 3 4 5 6 0)
2. Turn the handle within 3 seconds into opening position.

3. Locking

1. Close the door at the safe and turn the handle into locking position.

4. Programming the user code

The master is able to program the user code, but not vice versa.

1. Press and hold the key "1" until the red LEDs flash permanently.
2. Enter your 6-digit **master code** respectively 7 digits if "duress alarm" function is active.
3. Enter the 1-digit **user No.** which has to be programmed (between 1 and 9).
4. Enter the new 6-digit **user code** respectively 7 digits if "duress alarm" function is active.
5. Re-enter the new 6-digit **user code** respectively 7 digits if "duress alarm" function is active.

5. Changing the master or user code

1. Press and hold the key "0" until the red LEDs flash permanently.
2. Enter your **old** 6-digit code respectively 7 digits if "duress alarm" function is active.
3. Enter your **new** 6-digit code respectively 7 digits if "duress alarm" function is active.
4. Re-enter your **new** 6-digit code respectively 7 digits if "duress alarm" function is active.